

Next Steps

This section explains where to find information on using and maintaining KumoScale for Appliance Mode

Now that you have installed and configured the KumoScale storage cluster with masters and other storage nodes, you are ready to explore additional features of KumoScale software documented in the [KumoScale User Guide](#). The guide will explain how to customize your deployment, how to use logging and monitoring tools, and how to support the KumoScale software solution.

Depending on your environment you may also need to reference one or more of these documents available at *KumoScale software version 3.22 documentation*.

- [KumoScale Software Ansible Module User Guide](#): Installation and user guide for the KumoScale software Ansible™ modules and playbooks.
- [KumoScale CLI Guides](#): Reference and user guides for KumoScale CLI tools.
- [KumoScale CSI Driver User Guide](#): Installation and user guide for the KumoScale CSI driver used for Kubernetes orchestration.
- [KumoScale Software OpenStack Platform User Guide](#): Installation and user guide of KumoScale software components for integration with OpenStack™ environments.
- *KumoScale REST API*: KumoScale software REST APIs for Storage Nodes and the [REST API for Provisioner](#).
- [Maintaining and Using KumoScale for Appliance Mode](#) explains how to maintain and use KumoScale software.