

Using the KumoScale Engine in Managed Mode

This page lists how to stop, start, and restart the KumoScale Engine used in Managed Mode.

KumoScale Engine Service Operations

To stop the engine service, run:

```
service KumoScale stop
```

To start the engine service, run:

```
service KumoScale start
```

To restart the engine service, run:

```
service KumoScale restart
```