

Troubleshooting KumoScale Installation for Managed Mode

This section contains some tips for resolving issues that could arise when installing KumoScale for Managed Mode

Issue: Storage Nodes are in Pending Mode due to Errors

You may receive notification of storage nodes being in Pending mode due to errors. The following are some of the issues you may encounter and how they may be resolved.

Password Error: If an invalid password is provided to the KumoScale secret, you will receive an error when adding a storage node. The default password for admin will not work and you must set a new password as explained in step 4 of [Set up your Storage Cluster to use the Provisioner](#).

Volumes fail to add: You must install the CSI driver before requesting volumes. Install the CSI as instructed in *Next Steps* of [Adding Storage Nodes to a Kubernetes Cluster](#).
